


accessori per mobili



0730D



0730C



0730B



0730A



0725D



0725C



0725B



0725A

POMOLINI PER MOBILI
Knobs for furniture

"BOCCIA" O.L.V./O.F.G./O.CR./ONIKS

Art.0725A ø 18 mm

Art.0725B ø 22 mm

Art.0725C ø 26 mm

Art.0725D ø 30 mm

"CIPOLLA" O.L.V./O.F.G./O.CR./ONIKS

Art.0730A ø 22 mm

Art.0730B ø 28 mm

Art.0730C ø 34 mm

Art.0730D ø 40 mm

accessori per mobili



0737D



0739D



0737C



0739C



0737B



0739B



0737A



0739A

POMOLINI PER MOBILI
Knobs for furniture

"PORCELLANA"

Art.0737A-0739A ø 26 mm

Art.0737B-0739B ø 31 mm

Art.0737C-0739C ø 34X24 mm

Art.0737D-0739D ø 41X25 mm

accessori per mobili



0738D



0735D



0738C



0735C



0738B



0735B



0738A



0735A

POMOLINI PER MOBILI
Knobs for furniture

"PORCELLANA"

Art.0735A-0738A ø 26 mm

Art.0735B-0738B ø 31 mm

Art.0735C-0738C ø 34X24 mm

Art.0735D-0738D ø 41X25 mm